

All the Repair Parts You Need—in One Place!

Find-It-Fast Oven Repair Chart

Make	GE®	GE®	GE®	Whirlpool®	Whirlpool®	Hotpoint®	GE®	Whirlpool®
Type	Electric	Electric	Electric	Electric	Electric	Gas	Gas	Gas
Model	JBS07M	JBP27DM	JBS15M	RF114PXS	RF263LXT	RGB508PPH	JGBS07DEM	WFG110AV
HD Supply Part #	285049 285198 285319	285082 285310 285313	287016	285430 285435	285010 285645	285112 285174	285073 285152 285320	285020
Control Panel & Cooktop								
Drip Bowl - 6"	229675	229675	229675	229775	229775	N/A	N/A	N/A
Drip Bowl - 8"	229680	229680	229680	229800	229800	N/A	N/A	N/A
Surface Range Element - 6"	234710	234710	234710	233750	233750	N/A	N/A	N/A
Surface Range Element - 8"	234715	234715	234715	234000	234000	N/A	N/A	N/A
Surface Range Receptacle	220910	220910	220910	231650	231650	N/A	N/A	N/A
Infinite Switch Control - 6"	220715*	220715*	220740*	220755*	220755*	N/A	N/A	N/A
Infinite Switch Control - 8"	220735*	220735*	220745*	220760*	220760*	N/A	N/A	N/A
Infinite Knob - White	214940	214940	214940	214960	214960	N/A	214990*	214988*
Infinite Knob - Bisque	214941*	214941*	N/A	214961*	214961*	N/A	214991*	N/A
Infinite Knob - Black	214942*	214942*	N/A	214962*	214962*	214986*	214992*	N/A
Oven Thermostat Knob - White	214980*	N/A	214985*	N/A	N/A	N/A	214995*	214989*
Oven Thermostat Knob - Bisque	214981*	N/A	N/A	N/A	N/A	N/A	214996*	N/A
Oven Thermostat Knob - Black	214982*	N/A	N/A	N/A	N/A	214987*	214997*	N/A
Gas Range Double Burner	N/A	N/A	N/A	N/A	N/A	206118	206118	N/A
Gas Oven Igniter	N/A	N/A	N/A	N/A	N/A	N/A	226920	226930*
Body Parts								
Bake Element	237635	237640*	237635	237700*	237700*	N/A	N/A	N/A
Broil Element	237650*	237650*	237650*	237710*	237710*	N/A	N/A	N/A
Oven Thermostat	N/A	N/A	N/A	N/A	N/A	221675*	N/A	221750*
Oven Rack	228540*	228540*	228540*	228545*	228545*	228540*	228540*	228535*
Oven Lamp	308206*	308206*	308206*	308206*	308206*	N/A	308206*	N/A
Door & Drawer								
Oven Gasket	209025*	209095*	209075*	209030*	209035*	209075*	209075*	209040*
Oven Door Handle - White	209310*	209310*	209310*	209320*	209320*	209315*	209290*	209295*
Oven Door Handle - Bisque	209311*	209311*	N/A	209321*	209321*	N/A	209291*	N/A
Oven Door Handle - Black	209312*	209312*	N/A	209322*	209322*	N/A	209292*	N/A
Accessories								
Range Cord - 30 Amp - 3 Wire	301471	301471	301471	301471	301471	N/A	N/A	N/A
Range Cord - 50 Amp - 4 Wire	301473	301473	301473	301473	301473	N/A	N/A	N/A
Anti-Tip Kit	227550	227550	227550	227550	227550	227550	227550	227550
Oven Broiler Pan	228505	228505	228505	228505	228505	228505	228505	228505

*Factory Direct: Delivery in 3 to 7 business days. Freight charges may apply in some areas.



Find-It-Fast Refrigerator Repair Chart

Make	Hotpoint®	GE®	GE®	GE®	Whirlpool®	Whirlpool®	Whirlpool®	Whirlpool®
Model	HTR16AB	GTS17BBS	GTS18CBS	GTS18HCS	ETOMSRXT	ET4WSKXS	ET6WSKXS	ET8WTKXV
HD Supply Part #	285100 285101 285108 285109	285052 285085 285587 285075 285392	285941 285942	285506 285673 285077	285931	285200 285205	285210 285215	285258 285095
Liner/Unit Repair								
Defrost Control	230137	230137	230137	230137	230162*	230160*	230150*	230155*
Thermostat Temp Control	287070*	287070*	287070*	287070*	287075*	287076*	287077*	287078*
Evaporator Fan Motor	250356	250356	250356	250356	250359*	250372*	250366*	250366*
Refrigerator Lamp	327303	327303	327303	327303	327303	327303	327303	327303
Cabinet Repair								
Refrigerator (Full Width) Shelf	287195*	287195*	287195*	287196*	287198*	287199*	287199*	287197*
Crisper Cover	203022	203022	203022	203079*	203091*	203089*	203090*	203091*
Replacement Glass	N/A	N/A	N/A	203080*	N/A	N/A	N/A	203092*
Crisper Pan	204066	204026	204026	204036*	204031*	204032*	204032*	204033*
Gaskets								
Gasket - Refrigerator	206660	206670	206675	206675	206697*	206692*	206694*	206696*
Gasket - Freezer	206680*	206680*	206680*	206680*	206699*	206690*	206690*	206690*
Refrigerator Door Shelf/Bar								
Upper Door	N/A	N/A	204040*	204040*	206271*	206162*	206169*	206162*
End Cap	N/A	N/A	N/A	N/A	N/A	206160*	206160*	206160*
Middle Door	204040*	204040*	204040*	204040*	206270*	206132*	206167*	206166*
End Cap	N/A	N/A	N/A	N/A	N/A	206130*	206120*	206120*
Lower Bottom	204040*	204040*	204038*	204037*	206272*	206166*	206167*	206166*
End Cap	N/A	N/A	N/A	N/A	N/A	206120*	206120*	206120*
Dairy Door/Bar	N/A	204030*	204030*	204034*	206079*	N/A	N/A	206080*
Freezer Door Shelf/Bar								
Upper Door	204042*	204042*	204042*	204042*	206273*	206132*	206139*	206132*
End Cap	N/A	N/A	N/A	N/A	206274*	206130*	206130*	206130*
Bottom Door	204042*	204042*	204042*	204042*	206276*	206132*	206139*	206132*
End Cap	N/A	N/A	N/A	N/A	N/A	206130*	206130*	206130*
Refrigerator Door Handle								
White	N/A	206200*	206200*	206200*	N/A	206215*	206215*	206215*
Bisque	N/A	206201*	206201*	206201*	N/A	206216*	206216*	206216*
Black	N/A	206202*	N/A	206202*	N/A	N/A	N/A	206217*
Freezer Door Handle								
White	N/A	206210*	206210*	206210*	N/A	206230*	206230*	206230*
Bisque	N/A	206211*	206211*	206211*	N/A	206231*	206231*	206231*
Black	N/A	206212*	N/A	206212*	N/A	N/A	N/A	206232*
Accessories								
Icemaker	203465	203465	203465	203465	N/A	127360	127360	127360
Freezer Shelf	285062	285062	285062	285062	206093*	206090*	206091*	209092*

*Factory Direct: Delivery in 3 to 7 business days. Freight charges may apply in some areas.

